


9921013COMCLUKWhite
9921408COMCLUKGraphiteGrey
CosmoSinglePedDesk



Date of Purchase ___ / ___ / ___
Lot Number:



THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Do Not Return This Product!


Contact our customer service team for help first.

Call: 01942 524100

Email: cseurope@dorel.com

WARNING

- Unit can tip over causing severe injury or death.
- Anchor unit to stud in wall (if instructed to).
- Do Not allow children to climb on unit.
- Put heavy items on lower shelves or drawers.



Assembly Difficulty Meter


COSMOLiving


by COSMOPOLITAN

Helpful Hints


PEOPLE NEEDED FOR ASSEMBLY: **1-2**
ESTIMATED ASSEMBLY TIME: **1 HOUR**

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with a **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- Use all the nails provided for the back panel and spread them out equally.
- Back panel must be used to make sure your unit is sturdy.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.






Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.


Cam Lock Fastening System

This Cam Lock Fastening System will be used throughout the assembly process.




Board Identification

Not actual size




A

TOP PANEL
T9921013010KX




B

LEFT SIDE PANEL
T9921013020KX




C

RIGHT SIDE PANEL
T9921013030KX




D

BACK PANEL
T9921013040KX




E

FIXED SHELF
T9921013050KX




F

ADJ-SHELF
T9921013060KX



G

DRAWER LEFT PANEL
T9921013070KX




H

DRAWER RIGHT PANEL
T9921013080KX


Board Identification

Not actual size




Ⓡ

DRAWER FRONT PANEL
T9921013090KX




Ⓣ

DRAWER BACK PANEL
T9921013100KX




Ⓚ

DRAWER FRONT
T9921013110KX




Ⓛ

BOTTOM PANEL
T9921013120KX




Ⓜ

DRAWER BOTTOM PANEL
T9921013130KX




Ⓝ

RIGHT FRAME
T9921013140KX




Ⓞ

LEFT FRAME
T9921013150KX




Ⓟ

SHORT LINKING BAR
T9921013160KX



Ⓡ

FILE HANGER
T9921013180KX
QTY:2PCS




Ⓠ

LONG LINKING BAR
T9921013170KX


Board Identification

Not actual size




Part List


Actual Size




BOLT
TKX0027




BOLT
TKX0021




WOOD DOWEL
TKX0008




WOOD DOWEL
TKX0009




CAM BOLT
TKX0006



CAM LOCK
TKX0007




SCREW
TKX0020




BOLT
TKX0026


Not Actual Size




SHELF SUPPORT
TKX0024



HEX KEY
TKX0018







HANDLE
TKX0025







CAP
TKX0093

STEP 1





1.1 Screw (5) into (A) , (B) , (C) & (L) as illustrated.



1.2 Insert (3) into (B) & (C) as illustrated.





STEP 2





2.1 Insert (3) into (D) & (E) as illustrated.




2.2 Insert (4) into (I) & (J) as illustrated.






STEP 3



- 3.1 Attach (D) to (B) with (6) as illustrated.
- 3.2 Attach (E) to (B) with (6) as illustrated.
- 3.3 Attach (C) to (D) & (E) with (6) as illustrated.




STEP 4






4.1 Attach (A) to (B) & (C) & (D) with (6) & (12) as illustrated.

4.2 Attach (L) to (B) & (C) & (D) with (6) as illustrated.




STEP 5




5.1 Attach (O) & (N) to (A) & (L) with (1) as illustrated.

5.2 Attach (P) to (O) & (B) & (A) with (2) as illustrated.

5.3 Attach (Q) to (O) & (N) & (L) with (2) as illustrated.




STEP 6




6.1 Attach (G) to (I) & (J) with (7) as illustrated.

6.2 Insert (M) into (G), (I) & (J) as illustrated.

6.3 Attach (H) to (I) & (J) with (7) as illustrated.




STEP 7




7.1 Attach (K) to (I) with (8) & (11) as illustrated.

7.2 Place (R) into (G) & (H) as illustrated.




PS: if people like the line pattern, they can turn the pattern surface of the drawer panel outside before installation.

STEP 8




8.1 Put (9) into (B) & (C) as illustrated.

8.2 Place Drawer & (F) into desk as illustrated.



Maximum Loads

This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.



Warning: Risk of injury to persons - do not place a television on this furniture. This furniture is not approved for use with a television.
